



2 SQ NO. 30 ASPHALT FELT

Description & Uses

A heavy-weight asphalt roofing felt made of a specially formulated organic sheet which has been fully saturated with waterproofing asphalt. This sheet is pre-conditioned to lay flat and remain stable during and after installation. Application guidelines are provided every 2" across the sheet to aid the roofer in keeping asphalt shingles aligned.

May be used as an eave protector on sloped roofing or as a complete high performance underlayment beneath heavy roofing such as tile or metal.

Physical Test Parameters

Conforms to ASTM D4869 Type III; CSA A123.3 Type 3

Average Breaking Strength

Along Fibre Grain > 7kN/m (40 lb/in)

Across Fibre Grain > 3.5kN/m (20 lb/in)

Packaging

Roll Width 36" (0.914 m)

Roll Contents 216 sq. ft. (20.07 m²)

Rolls per Pallet 25

Weight per Roll 48 lbs approx.

Pallet Size 48" x 40"

Deck Preparation

Proper deck preparation is an essential step to ensure that the roofing remains problem free.

When preparing roof deck:

- Follow all instructions supplied by the manufacturer of the shingles or other roofing.
- Remove and replace any broken or decaying lumber.
- Remove loose nails and ensure that all decking is securely fastened to sound framing members with proper fasteners.
- If installing new O.S.B. sheathing, allow a **3/16" gap** at end joints and **1/8" gap** at side joints.

Attic Humidity

Check for adequate ventilation under the roof deck. High humidity due to improper attic venting can cause wrinkles or ridging to occur in some roofing materials. It can also cause new plywood or O.S.B. to expand excessively which may also cause ridging in the roofing materials. Problems caused by high humidity are usually of an aesthetic nature and may not be protected by roofing material warranties.

Underlayment Installation

2 Sq No. 30 Asphalt Felt is a heavy sheet which suits a heavier style of finished roofing. When used under lightweight roofing, such as asphalt shingles, 2 Sq No. 30 Asphalt Felt may telegraph expansion ripples to the shingles when deck humidity is excessive.

To help avoid this problem:

- Roll the felt out and allow it to warm up before fastening down.
- Cut the felt into shorter segments (approx. 15 ft.) to reduce expansion potential.
- Install extra nails in the felt at the time the shingles are placed.
- Eliminate humidity problems by improving attic ventilation.



Address

9681 - 187th Street
Surrey, BC, Canada
V4N 3N3

Website

www.halind.com

Email

contact@halind.com

Local Number

604 888 0777

Toll Free Number

1 800 663 0076



On-site Quality Control

HAL felt products need to be kept on end and stored off the ground in a dry environment; this is to ensure that the product is in the right condition to be installed. HAL felt should not be stacked more than three pallets high.

Recommended Tools & Equipment

For felt installations, HAL recommends the use of plastic cap nails as fasteners.

Caution

Great care must be exercised in all phases of steep slope roof application. Follow the safety guidelines of the safety authority having jurisdiction in your area.

Revised December 6, 2023

The information provided herein, while not guaranteed, is to the best of our knowledge true and accurate. Except when agreed to in writing for specific conditions of use, no warranty or guarantee expressed or implied is made regarding the performance of any products, since the manner of use and handling are beyond our control. The user of such information assumes all risk connected with the use thereof. Nothing contained herein is to be construed as permission or as a recommendation to infringe any patent.